

PREMIUM CARPET UNDERLAYMENT INSTALLATION

Premium Carpet Underlayment consists of high quality closed cell foam bonded to a layer of mass loaded vinyl. This item is used in place of standard carpet underlayment and is installed in the same way.

First clean your floor of all debris and install tack strips.

Cut your Premium Carpet Underlayment to the needed length overlapping the tack strips slightly.

Be sure to layer the foam layer on the floor with the black vinyl layer facing upwards. Butt the edges together as tightly as possible. A strip of vinyl tape can be used to secure the edges.

Once you are done laying down the underlayment, cut the edges to fit in front of the tack strips. We recommend to not staple down the underlayment however if your installer is concerned with movement of the underlayment, you can staple it down at a few points.

Now you can install your carpet as you would over any standard underlayment.

Your finished room will look no different and will have a firmer feel when walking on the carpet.

