Trademark SOUNDPROOFING

Foamtak Spray Adhesive

Installation Instructions

Thank you for buying our new and improved version of Auralex Foamtak Spray Adhesive! Please follow all the directions and precautions printed on our can.

Installation Tips:

• Depending on how strong you want Foamtak to bond to the mounting surface, you can either spray your acoustic foam or the wall or both.

• Hold the can approximately 12-18” from the Studiofoam or room surface and shake the can from side to side to yield a “spider web” pattern.

• You can either stick your acoustic foam to the wall immediately after spraying it or let the Foamtak cure for about 1 minute before sticking the foam into place. This provides the strongest long-term bond and is the recommended method when mounting Venus Bass Traps, LENRDs and in some cases 4” Studiofoam.

• You don't have to spray the back of each piece of foam entirely for Foamtak to work (especially with thinner foam), but naturally, the more Foamtak you apply, the better adhesion you'll achieve.

• Begin spraying in the center of the foam, then work out toward the edges, being careful not to get within 1/2” or so of the edges to minimize over spray getting on a part of the foam where it might show.

• Storing the Foamtak can upside down between applications may allow a more consistent spray pattern.

• Use the Studiofoam box lids as spray guards for cleaner installation.

• Stacking two Studiofoam boxes may yield a convenient work surface.

Total Sound Control
Auralex acoustics
www.auralex.com

148 Horton Drive, Suite B
Monsey, New York, 10952

Phone: 845.352.3200
Fax: 845.367.4657

www.TMSoundproofing.com