Trademark SOUNDPROOFING

Fabric Acoustic Wall Panels

Installation Instructions

Impaling hooks are the recommended installation method for all locations where panels do not need to be moved. Impaling hooks are provided with each order of acoustic panels.

Before you begin:

• Decide on panel layout; inspect mounting surfaces to determine suitability for installing panels.

• Determine clip locations on the wall using a pencil and straight edge to ensure proper placement of clips. Clips should be evenly spaced on the back of the panel.

• Clips should be aligned to meet up with the fiberglass section of the panel past the point where the excess fabric ends.

• For panels up to 24”X48”, 6 impaling clips are recommended. For larger panels, 6-8 clips are recommended.

Installation:

• Drill screws into each impaling clip to firmly anchor the clips to the wall.

• It is recommended that adhesive be used in conjunction with impaling clips to ensure secure attachment of the clips.

• Apply adhesive to the wall surface as well as the back of the panel.

• Firmly attach the panel to the wall pressing evenly to ensure complete adhesion. You can use a clean piece of plywood to firmly distribute pressure on the clip.

• DO NOT PULL PANEL AWAY FROM THE WALL AT THIS POINT AS THIS WILL BREAK THE BOND BEFORE THE GLUE HAS A CHANCE TO SET.

148 Horton Drive, Suite B
Monsey, New York, 10952

Phone: 845.352.3200
Fax: 845.367.4657

www.TMSoundproofing.com